

21022_ESTACIÓN METEOROLÓGICA MAGINLY

FRONT PART

21022 - Estación Meteorológica Maginly Manual de instrucciones (Esp)



Recomendamos que lea detenidamente este manual de instrucciones y lo conserve para futuras consultas.

Descripción del Producto:



Especificaciones:

- Rango de temperatura (0-50°C, 32-122°F). Precisión +/-1°C
- Calendario
- Alarma
- Rango de humedad (20-99%). Precisión +/- 1%
- Formato hora 12/24h.
- Temperatura y humedad máxima y mínima.
- Icono de confort y tiempo.
- Tendencia de temperatura.

Funcionamiento:

Quite la tapa trasera del dispositivo e introduzca dos pilas AAA.

Configuración :

Mantenga pulsado el boton MODE durante 3 segundos para entrar en el modo configuración y ajustar la fecha y hora. Los dígitos comenzaran a parpadear. A continuación, pulse o mantenga pulsado UP/ DOWN para ajustarlos y de nuevo MODE para fijar los valores deseados.

Mantenga pulsado UP para cambiar el formato de hora (12/24h)

Desde el menú principal, pulse MODE para acceder al calendario y pulse nuevamente para acceder a la alarma. En la pantalla deseada, mantenga pulsada la tecla MODE para configurar los valores y pulse UP/DOWN para su ajuste.

Pulse el botón LIGHT para activar la retroiluminación de la pantalla.

ALARMA:

Pulse el boton UP para activar/desactivar la alarma. Cuando la misma esté activada, el icono  aparecerá en la pantalla.

Pulse UP para parar la alarma.

Nota: La alarma se detendrá tras dos minutos y se activará a la misma hora el día siguiente.

Puede detener la alarma durante 8 minutos pulsando el botón SNZ mientras la misma está sonando.

TEMPERATURA Y HUMEDAD MÁXIMA/MÍNIMA:

- Pulse MAX/MIN una vez para visualizar la temperatura y humedad máxima alcanzada, y pulse nuevamente para visualizar los valores mínimos alcanzados.

Pulse el botón DOWN para cambiar la medición de la temperatura (°C, °F)

El dispositivo muestra en pantalla otras funciones como:

- Icono del tiempo actual: Soleado, nublado o con lluvia.
- Nivel de confort: se muestran tres caras diferentes en función de los valores del tiempo.



Buen tiempo



Intermedio



Mal tiempo

Advertencias:

1. Para uso interior: No lo exponga a la lluvia o entornos mojados.
2. Evite caídas que le puedan generar daños serios.
3. No intente reparar la unidad por sí mismo, contacte con un especialista.
4. Para evitar riesgos, no se deshaga de él de manera inapropiada.
5. Límpielo con un trapo seco.
6. No lo instale cerca de fuentes de calor o luz solar directa.
7. No inserte ningún objeto metálico en la unidad, existirá la posibilidad de un cortocircuito.
8. Mantenga fuera del alcance de los niños.



El símbolo de referencia tanto en el producto como en su manual de usuario, indica que al final de la vida útil de los aparatos electrónicos y/o electrónicos, estos deberán reciclarse por separado de sus residuos domésticos. Existen medios adecuados para recoger este tipo de material para su correcto reciclaje. Para obtener más información, póngase en contacto con la autoridad local. Antes de entregar los RAEE se deben extraer las pilas.

MKTO CATAL IMPORTACIONES S.L. B04267225
Ctra. Huércal-Overa, S/N 04640 Puñal, Almería, España
productsafety@makito.es

BACK PART

21022 - Weather Station Maginly User manual (Eng)



It is recommended to read this user manual carefully and keep it for future reference.

Product overview:



Specificacions:

- Temperature range (0-50°C, 32-122°F). Accuracy +/- 1°C.
- Calendar
- Alarm
- Humidity range (20-99%). Accuracy +/- 1%.
- 12/24h format.
- Max/Min temperature and humidity.
- Comfort and weather icons.
- Temperature trend.

Operation:

Remove the lid of the battery compartment and insert two AAA batteries.

To set date and time:

To adjust the date and time, press MODE button for 3 seconds to enter into setting mode. The digits will start to flash. Press the UP/DOWN button to adjust or hold down the button to change the digits quickly. Once you have selected the correct date and time, press the MODE button again to save.

Long press UP to change the hour format (12/24h)

From the main menu press MODE to enter into Calendar and press again to go to Alarm. When in these modes, long press the MODE button to set and press UP/DOWN buttons to adjust.

Press the LIGHT button to activate the screen backlight.

ALARMA:

Press UP button to activate/deactivate the alarm. The  icon will show on the screen when the alarm is activated.

Press UP to stop the alarm.

Note: The alarm will stop after two minutes and will be automatically activated at same time for the following day.

To snooze, press the SNZ button when the alarm is sounding and it will repeat after 8 minutes.

MAX/MIN TEMPERATURE AND HUMIDITY:

- Press MAX/MIN once to check the maximum temperature and humidity reached, and press again to check the minimum measurements.

Press DOWN button to change the temperature setting (°C or °F)

The weather station also displays other functions such as:

- Actual Weather icon: Sunny, cloudy or rain.

- Comfort level: Displays three different emojis according the weather.



Nice weather



Average



Bad weather

Warnings:

1. For interior use: Do not expose this product to rain or damp conditions.
2. Prevent this item from falling as it could cause serious damage.
3. Do not dismantle, repair or modify this product by yourself, contact an authorized specialist.
4. In order to avoid any risk, do not dispose of this product inappropriately.
5. Clean it with a dry cloth.
6. Do not place this item near sources of heat or expose to direct sunlight.
7. Do not insert any metal objects into this device as there is a risk of causing a short circuit in the unit.



This symbol both in the product and its user manual indicates that at the end of the devices electrical life, it should be recycled separately from your household waste. There are adequate means to dispose of this material for proper recycling. For more information, contact your local authorities. Before disposing the WEEE, please remove the batteries.

MKTO CATAL IMPORTACIONES S.L. B04267225
Ctra. Huércal-Overa, S/N 04640 Puñal, Almería, Spain
productsafety@makito.es