


FRONT PART

6044_TROLLEY KLEINTOR



BACK PART



USER INSTRUCTIONS

The default combination code is 0-0-0

To set a new combination code use the following steps:

1. Using a pointed object as shown in picture (1) push in the reset button until you here a click sound.
2. Turn the dials to set your own combination code.
3. Press the lock release button firmly (picture 2) in the direction of the arrow until it clicks.
Your new combination code has now been set.

INSTRUCCIONES DE USO:

La combinación por defecto es 0-0-0.

Para cambiar la combinación, siga los siguientes pasos:

1. Con el uso de un objeto afilado, pulse el botón de desbloqueo.
2. Seleccione la combinación deseada.
3. Presionar el botón de apertura hasta que escuche el clic.
En este momento, la combinación se habrá guardado.